

HEAT RESISTANT SYNTHETIC STYLING GUIDE



PREPERATION

- Heat your curling iron or flat iron to 270 - 280 F
- Gently remove any tangles using your pick/wide tooth comb
- Apply Restore (Heat Treatment/Conditioner spray) to each section before using your hot tools.

WIG BLOCKING

Using ball-head pins and your care mannequin, secure your wig with pins at the temples and both sides of the nape. Ensure that the wig/topper is flush to the mannequin so that it is properly blocked.



CURLING



- Spray Restore into section, gather section into curling iron, smooth through to ends & roll iron towards the base of the wig/topper, **Staying away 1"-2" away from base.**
- Hold for 10-15 seconds, then turn the tip of the curling iron towards the ground and release curl into the palm of your hand.
- Holding curl in one hand, gather up towards base and secure curl with a small metal clip (like a pin curl)
- Allow curl to cool completely (about 5 mins), then remove clip and let curl hang naturally or comb out.

FLAT IRONING

- Starting at the nape, Spray Restore into 0.5' - 1.5" sections
- Slowly smooth flat iron down through ends while keeping the hair smooth by following behind the flat iron with your wide tooth comb.
- allow hair to naturally cool completely



TIPS

- All synthetic fibers can tangle and frizz with wear. It is important that the frizz is corrected early to avoid permanent damage to the fibers. use your flat iron to smooth any frizz before washing.
- Spray your conditioner lightly every week and pick through your wig gently to help slow the frizzing process.

We at Studio 409 Hair Loss Clinic offer washing, deep conditioning, restyling, restoration & cutting of wigs and topper.

If you have any questions please call 515-457-9534 or email us at Studio409.HairLoss@gmail.com